

LEMAR



INSTALLATION INSTRUCTIONS FOR DUMMY LEVER

- * Scribe required drilling centres using template below
- * Drill 2 x 8 mm holes through door
- * Screw in threaded sleeves into handle assembly and position lever on door
- * Tighten from back of door using screws and cup washers provided

CHANGE HANDING (Vigo levers only)

- * Loosen grub screw under lever shaft
- * Remove the dome headed pin from face of lever
- * Remove lever and reverse
- * insert pin and tighten grub screw

Fold here on door edge

