



# LEMAAR

ARTISTRY IN DOOR FURNITURE

## 56400 Surface Mounted Indicator Bolt



### TOOLS REQUIRED:

Drill	Drill Bit: 3mm + 12mm	Screwdriver: Phillips	Pliers	Pencil	Ruler
-------	-----------------------	-----------------------	--------	--------	-------

### FITTING INSTRUCTIONS:

#### NEW DOOR PREPERATION:

1. Make a centre line on your door at the desired height.
2. Mark Drill Point 34mm from Door Edge. Drill 12mm Hole **(Image A)**
3. Position the Lock Case on the door, centre the spindle inside the 12mm hole.
4. Fix Lock Case with 4 screws provided.
5. Insert the spindle into the Lock Case from outside the door. Cut the Spindle 10mm longer than the door edge **(Image B)**
6. Place Vacant/Engage Plate onto door. Mark screw hole positions and fix to the door with the screws supplied. Check the function of the lock.

#### INSTALLATION OF STRIKE PLATE

7. Place the strike onto the frame at the correct height to ensure locking. Mark screw hole positions and fix to the door with the screws supplied. Check the function of the lock. **(Image C)**

